


# Intellijel Steppy 1U Cheat Sheet

## SELECT Menu:

Press-and-hold SELECT to briefly activate the menu.  
Or short-click SELECT to toggle the select mode on/off



**Clear:** Long-press (>1sec) also resets EDIT menu options for selected track

**Reset:** (Panic-mode)

Long-press (>1sec) of the reset also sends a gate-off to all channels.

**Copy Track/Page:** Enter select mode, push-and-hold a Track or Page, then click a destination for the copy, release both buttons.

**LOOPY mode:** when engaged the SELECT/EDIT lights alternately flash.








Loops between held-down buttons.

*Red, Green, Yellow* indicate: active step, looped steps, and non-looped steps

## EDIT Menu:

(Changes settings for all steps in the selected track)

Long-pressing (>1sec) the value-setting applies the setting to all 4 tracks.




## Per-Step Ratcheting:

Press and hold EDIT until the LED blinks  
Select the step (step 9), and then select the amount (8 ratchets) on the opposing row (circled).

Press either the current step or edit to exit that step.

Long-press (>1sec) EDIT to exit ratcheting mode.

Press-and-hold a step and click a 2nd step to copy ratchets



## Tap Recording:

Hold SELECT and then press EDIT.

When engaged the SELECT/EDIT lights pulse in unison

Long-press (>1sec) EDIT to exit